



Permaroof FAQs on Flat Roofing

Frequently Asked Questions

We offer a range of roofing and building solutions to tradesmen, stockists, and directly to consumers. Long term solutions to age old problems. Partnering with some of the biggest names in the industry, we have a long history of quality and excellence.



 www.permarroof.co.uk

 sales@permarrroof.co.uk

 01773 608839

Frequently Asked Questions

What is Firestone RubberCover membrane?

Firestone RubberCover EPDM is a 100% cured single-ply roofing membrane made of a synthetic rubber Ethylene-Propylene-Diene Terpolymer. Since 1980, more than 1,000,000,000 square metres of Firestone EPDM membranes have been successfully installed on commercial, industrial and residential roofs worldwide. Various roll sizes, the biggest being 15m wide and 61m long.

Does the membrane have an up- and downside?

No, there is no difference between the top and bottom of the membrane. On fire-rated (FR grade) membrane, there is clear wording stating which side this membrane should be laid.

Does the membrane require a protective topcoat?

No, the membrane is resistant to UV rays and ozone.

How long will the membrane last?

The membranes offer unmatched resistance to UV radiation, ozone, alkali rains and high or low temperatures. Recent studies show that the membrane has a life expectancy of more than 50 years, even when exposed to sunlight.

Is maintenance required?

No specific maintenance is required for a Firestone RubberCover EPDM roofing system. However, a yearly inspection of the roof is recommended.

Can certain materials damage the membrane?

The membrane is less resistant to oil products. This category includes mineral and vegetable oils, petroleum based products, fresh bitumen and grease, and contact with these products should be avoided.

How can the membrane be repaired?

For flat areas, the membrane can be easily repaired with a piece of Quickseam SA flashing. For damage at angle changes, a Quickseam Corner Flashing patch must be used instead.

Is the membrane available in different colours?

No, the membrane is only available in slate grey.

Which substrates can I adhere the membrane to?

Either OSB3 sterling board or plywood timber, but smooth concrete and tissue-faced insulation boards are also suitable. Note that new concrete should be fully cured before membrane installation and this takes a minimum of 28 days.

Installing the membrane over an existing asphalt surface is not recommended. Installation of a timber overlay or insulation board mechanically fixed through the asphalt into the roof deck is required. The membrane can then be adhered normally on these boards.

Can the membrane be applied to a wet surface?

No. Ponded water, snow, frost and ice must be removed from the roof surface before installation of the membrane.

Does the roof need cleaning before laying EPDM?

The surface must be clean, smooth, dry and free of sharp and/or loose particles, fasteners, debris and/or foreign materials such as oil, grease, bitumen residue and other contaminants before application of the membrane.

Is the membrane installation weather dependent?

Yes, the minimum temperature for application of the adhesives is +5°C and the maximum humidity is 80%.

If the temperature is likely to drop below freezing during the following 48 hours after application, Firestone Bonding Adhesive must be used instead.

Is adhesive applied to both roof and membrane?

Bonding adhesive must always be applied to both surfaces. Water-based adhesive can be applied to either the substrate only (wet mate method) or using the two-sided contact method. i.e. both to the underside of the membrane and the substrate.

Weather conditions can influence which application type suits your requirements.

Can the adhesive be left too long to flash off?

Yes. After the adhesive is applied and has flashed off, the surfaces are ready to be mated together. If the prepared surfaces are left open longer than necessary, there is a risk of dust and debris falling onto these areas.

Also, high temperatures as well as falling cooler temperatures and moisture can affect the performance of the adhesives if the prepared surfaces are left open too long.

Why do bubbles or wrinkles form on the EPDM?

Solvents in the adhesives that are not allowed enough time to flash off cause bubbles or wrinkling. The wet adhesive distorts the membrane causing ripples.

Although the bubbles tend to recede, the membrane is unlikely to be adhered at these areas, and in varying weather conditions, the bubbles and air pockets could re-appear.

What are the coverage rates for the adhesives?

Approximate figures are as follows:

- Bonding adhesive is 2 sq. metres per litre.
- Water-based adhesive (two-sided application method) is 2 sq. metres per litre.
- Water-based adhesive (one-sided wet mate method) is 3 sq. metres per litre.

Does EPDM need prepping for QuickPrime Plus?

No, except when the membrane is excessively dirty, in which case it must be cleaned with water and a clean rag.

Which products require Firestone Quickprime Plus?

Firestone QuickPrime Plus primer must be used with ALL Firestone Quickseam products in order to clean and prime the membrane before application of the Quickseam products.

Are specific tools required for installation?

Yes, the Quickscriber tool for application of the QuickPrime Plus, a silicon hand roller and penny roller for application of the Quickseam products.

Are any precautions required during installation?

Both Bonding Adhesive and QuickPrime Plus can only be used in well ventilated areas. Both products must be kept away from ignition sources. Do not smoke when using. Firestone recommends wearing gloves when using QuickPrime Plus.

For further information, please consult the Material Safety Data Sheets as well as the information shown on the product labels. Visit the resource library [here](#).

Can the membrane touch a hot pipe penetration?

The use of double-skinned penetrations is required for flue pipes and other hot penetrations.

Can I walk on a Firestone RubberCover roof?

Yes, the roof can be accessed for periodical maintenance, but take care to ensure no sharp objects (e.g., small stones) are attached to the underside of footwear.

In case of regular foot traffic, the membrane must be protected with a walkway, e.g. pavers placed on protective rubber feet.

Can the membrane be used as a pond liner?

No, the membrane is only suitable for roofs and gutters.

The processes used in the manufacture of Firestone RubberCover EPDM are different to those used in the manufacture of EPDM pond liners, and if installed, could be potentially harmful to aquatic life.

Can the membrane be used for green roofing?

Yes, a sedum vegetation can be placed over the membrane provided that a root resistant geotextile is used between the vegetation and the membrane.

Please see our [green roof page](#) for further information.

Can the membrane be ballasted?

Yes, it is possible to cover the membrane with rounded washed bank river gravel and/or pavers placed on protective rubber feet, but the membrane must always be fully adhered to the substrate.

Firestone recommends the use of a geotextile polyester sheet between the membrane and the ballast.

Warranty cover with Firestone RubberCover EPDM?

Permaroof UK provides a 20 material-only warranty for installations carried out by Permaroof-trained contractors.

Permaroof UK Ltd

01773 608 839

permaroof.co.uk

Shop online

permaroofstore.co.uk

EPDM roofing training:

permaroof.co.uk/roofing-training-courses

Further EPDM resources:

permaroof.co.uk/diy-flat-roof-library

Visit our YouTube channel for tutorials:

youtube.com/user/PermaroofOnline/videos